



# Function List

AutoMaker:MINI

**NOTES:**

- √ This function is supported.
- This function is not supported.
- ※ This function may be supported, which depends on the actual condition of the vehicle.
- √ This function is the new feature in this version.

As for special function, please refer to the special function table.

Model Series	Part	Systems	Ecu Info.	Read DTC	Freeze Frame	Erase DTC	Live Data	Component activation	Physical HW
R50/R52/R53	Body	MRS/AB Airbag/ACSM	√	√	○	√	√	○	√
R50/R52/R53	Body	AIC Automatic Interval control	√	√	○	√	√	○	○
R50/R52/R53	Body	BM On-board monitor	√	√	○	√	√	√	○
R50/R52/R53	Body	CDC CD Changer	√	√	○	√	○	√	√
R50/R52/R53	Body	CVM/CVM2 Convertible top module	√	√	○	√	√	√	√
R50/R52/R53	Body	DSP Digital Sound Processor	√	√	○	√	√	○	○
R50/R52/R53	Body	IHKA Heater/automatic A/C control	√	√	○	√	√	√	√
R50/R52/R53	Body	KOM Instrument cluster	√	√	○	√	√	√	○
R50/R52/R53	Body	LRA Automatic headlight vertical aim control	√	√	○	√	√	√	○
R50/R52/R53	Body	MFL Multifunction steering wheel I	√	√	○	√	○	○	○
R50/R52/R53	Body	MFL Multifunction steering wheel II	√	√	○	√	○	○	○
R50/R52/R53	Body	NAJ Navigation computer,Japan	√	√	○	√	√	√	○
R50/R52/R53	Body	NAV Navigation computer,Europe	√	√	○	√	√	○	○
R50/R52/R53	Body	PDC Park distance control	√	√	○	√	√	√	√
R50/R52/R53	Body	RAD Radio	√	√	○	√	√	√	√
R50/R52/R53	Body	RLS Rain/Light Sensor	√	√	○	√	√	○	√
R50/R52/R53	Body	SBBF Seat occupancy,passenger	√	√	○	√	√	○	○
R50/R52/R53	Body	SHD Sliding/tilting sunroof	√	√	○	√	√	√	√
R50/R52/R53	Body	ULF Universal charging and hands-free facility	√	√	○	√	√	√	√
R50/R52/R53	Body	VID Video module	√	√	○	√	○	○	○
R50/R52/R53	Body	ZKE Central body electronics BC1	√	√	○	√	√	√	○
R50/R52/R53	Body	ZKE Central body electronics BC1(Redesign)	√	√	○	√	√	√	○
R50/R52/R53	Chassis	ABS/ASC/DSC Dynamic Stability Control	√	√	○	√	√	√	√
R50/R52/R53	Chassis	EHPS Electro-hydraulic steering assistance	√	√	○	√	√	√	○
R50/R52/R53	Chassis	LEW Steering-angle sensor	√	√	○	√	√	○	○
R50/R52/R53	Chassis	RDC Tyre pressure control	√	√	○	√	√	√	√
R50/R52/R53	Chassis	RPW tyre-blowout warning system	√	√	○	√	√	○	○
R50/R52/R53	Drive	DME/DDE(Engine Electronics)	√	√	○	√	√	√	√
R50/R52/R53	Drive	EGS/AGS(Transmission Control)	√	√	○	√	√	√	√
R50/R52/R53	Drive	EWS Vehicle immobilizer	√	√	○	√	√	√	○
R55/R56/R57	Body	MRS/AB Airbag/ACSM	√	√	√	√	√	○	√
R55/R56/R57	Body	AHM Trailer module	√	√	√	√	√	√	√
R55/R56/R57	Body	AMPH Hi-Fi amplifier	√	√	√	√	√	√	√
R55/R56/R57	Body	CA Comfort access system	√	√	√	√	√	○	√
R55/R56/R57	Body	CAN communication analysis	√	√	√	○	○	○	○
R55/R56/R57	Body	CCC-A Applications	√	√	√	√	√	√	√
R55/R56/R57	Body	CCC-ANT Aerial tuner	√	√	√	√	√	√	√
R55/R56/R57	Body	CCC-ASK Audio system controller	√	√	√	√	√	√	√
R55/R56/R57	Body	CCC-BO User interface	√	√	√	√	√	√	√
R55/R56/R57	Body	CCC-GW Gateway	√	√	√	√	√	√	√
R55/R56/R57	Body	CDC CD Changer	√	√	√	√	○	√	√
R55/R56/R57	Body	CID Central information display	√	√	√	√	√	√	√
R55/R56/R57	Body	CVM/CVM2 Convertible top module	√	√	√	√	√	√	√
R55/R56/R57	Body	DAB Digital tuner	√	√	√	√	√	√	√
R55/R56/R57	Body	FRM footwell module	√	√	√	√	√	√	√
R55/R56/R57	Body	IBOC Digital tuner US	√	√	√	√	√	○	√
R55/R56/R57	Body	IHKA Heater/automatic A/C control	√	√	√	√	√	√	√
R55/R56/R57	Body	IHKS Integrated heating/air-conditioning control	√	√	√	√	√	√	√
R55/R56/R57	Body	IHS Integrated heating control	√	√	√	√	√	√	√
R55/R56/R57	Body	INSTR Instrument cluster	√	√	√	√	√	√	√
R55/R56/R57	Body	JBE Junction-box electronics	√	√	√	√	√	√	√
R55/R56/R57	Body	JNAV Navigation system,Japan	√	√	√	√	√	√	√
R55/R56/R57	Body	MJOY MINI joystick	√	√	√	√	√	√	√
R55/R56/R57	Body	MOST system analysis	√	√	√	√	○	○	○
R55/R56/R57	Body	PDC Park distance control	√	√	√	√	√	√	√
R55/R56/R57	Body	RAD Radio	√	√	√	√	√	√	√
R55/R56/R57	Body	RAD2-BO User interface	√	√	√	√	√	√	√
R55/R56/R57	Body	RAD2-GW Gateway	√	√	√	√	√	√	√
R55/R56/R57	Body	SDARS Satellite tuner	√	√	√	√	√	√	√
R55/R56/R57	Body	SHD Sliding/tilting sunroof	√	√	√	√	√	√	√
R55/R56/R57	Body	SZL Switch centre, steering column	√	√	√	√	√	√	√
R55/R56/R57	Body	ULF-SBX Interface box	√	√	√	√	√	√	√
R55/R56/R57	Body	ULF-SBX-H Interface box High	√	√	√	√	√	√	√
R55/R56/R57	Body	VM Video Module	√	√	√	√	√	√	√

R55/R56/R57	Chassis	ABS/ASC/DSC Dynamic Stability Control	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Chassis	EPS Electronic Power Steering	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Chassis	RDC Tyre pressure control	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Drive	CAS Car Access System	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Drive	DME/DDE(Engine Electronics)	✓	✓	✓	✓	✓	✓	✓
R55/R56/R57	Drive	EGS/AGS(Transmission Control)	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	MRS/AB Airbag/ACSM	✓	✓	✓	✓	✓	○	✓
R58/R59	Body	AHM Trailer module	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	AMPH Hi-Fi amplifier	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	CA Comfort access system	✓	✓	✓	✓	✓	○	✓
R58/R59	Body	CBX-ECALL Combox emergency call	✓	✓	✓	✓	✓	✓	○
R58/R59	Body	CHAMP-BO User interface	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	CHAMP-GW Gateway	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	CID Central information display	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	FRM footwell module	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	IBOC Digital tuner US	✓	✓	✓	✓	✓	○	✓
R58/R59	Body	IHKA Heater/automatic A/C control	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	INSTR Instrument cluster	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	JBE Junction-box electronics	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	MJOY MINI joystick	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	PDC Park distance control	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	SHD Sliding/tilting sunroof	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	SZL Steering column switch centre 2	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	ULF-SBX Interface box	✓	✓	✓	✓	✓	✓	✓
R58/R59	Body	ULF-SBX-H Interface box High	✓	✓	✓	✓	✓	✓	✓
R58/R59	Chassis	ABS/ASC/DSC Dynamic Stability Control	✓	✓	✓	✓	✓	✓	✓
R58/R59	Chassis	EDC Damper Control	✓	✓	✓	✓	✓	✓	✓
R58/R59	Chassis	EPS Electronic Power Steering	✓	✓	✓	✓	✓	✓	✓
R58/R59	Drive	CAS Car Access System	✓	✓	✓	✓	✓	✓	✓
R58/R59	Drive	DME/DDE(Engine Electronics)	✓	✓	✓	✓	✓	✓	✓
R58/R59	Drive	EGS/AGS(Transmission Control)	✓	✓	✓	✓	✓	✓	✓
R60	Body	MRS/AB Airbag/ACSM	✓	✓	✓	✓	✓	○	✓
R60	Body	AHM Trailer module	✓	✓	✓	✓	✓	✓	✓
R60	Body	AMPH Hi-Fi amplifier	✓	✓	✓	✓	✓	✓	✓
R60	Body	CA Comfort access system	✓	✓	✓	✓	✓	○	✓
R60	Body	CBX-ECALL Combox emergency call	✓	✓	✓	✓	✓	✓	○
R60	Body	CHAMP-BO User interface	✓	✓	✓	✓	✓	✓	✓
R60	Body	CHAMP-GW Gateway	✓	✓	✓	✓	✓	✓	✓
R60	Body	CID Central information display	✓	✓	✓	✓	✓	✓	✓
R60	Body	FRM footwell module	✓	✓	✓	✓	✓	✓	✓
R60	Body	IBOC Digital tuner US	✓	✓	✓	✓	✓	○	✓
R60	Body	IHKA Heater/automatic A/C control	✓	✓	✓	✓	✓	✓	✓
R60	Body	INSTR Instrument cluster	✓	✓	✓	✓	✓	✓	✓
R60	Body	JBE Junction-box electronics	✓	✓	✓	✓	✓	✓	✓
R60	Body	MJOY MINI joystick	✓	✓	✓	✓	✓	✓	✓
R60	Body	PDC Park distance control	✓	✓	✓	✓	✓	✓	✓
R60	Body	SHD Sliding/tilting sunroof	✓	✓	✓	✓	✓	✓	✓
R60	Body	SZL Steering column switch centre 2	✓	✓	✓	✓	✓	✓	✓
R60	Body	ULF-SBX Interface box	✓	✓	✓	✓	✓	✓	✓
R60	Body	ULF-SBX-H Interface box High	✓	✓	✓	✓	✓	✓	✓
R60	Chassis	ABS/ASC/DSC Dynamic Stability Control	✓	✓	✓	✓	✓	✓	✓
R60	Chassis	EDC Damper Control	✓	✓	✓	✓	✓	✓	✓
R60	Chassis	EPS Electronic Power Steering	✓	✓	✓	✓	✓	✓	✓
R60	Drive	CAS Car Access System	✓	✓	✓	✓	✓	✓	✓
R60	Drive	DME/DDE(Engine Electronics)	✓	✓	✓	✓	✓	✓	✓
R60	Drive	EGS/AGS(Transmission Control)	✓	✓	✓	✓	✓	✓	✓
F56	Body	MRS/AB Airbag/ACSM	✓	✓	✓	✓	✓	○	✓
F56	Body	AHM Trailer module	✓	✓	✓	✓	✓	✓	✓
F56	Body	AMPH Hi-Fi amplifier	✓	✓	✓	✓	✓	✓	✓
F56	Body	AMPT Top Hi-Fi amplifier	✓	✓	✓	✓	✓	✓	✓
F56	Body	ASD Active Sound Design	✓	✓	✓	✓	✓	✓	○
F56	Body	CBX-ECALL Combox emergency call	✓	✓	✓	✓	✓	✓	○
F56	Body	CIC Car Information Computer	✓	✓	✓	✓	✓	✓	✓
F56	Body	CON Controller	✓	✓	✓	✓	✓	✓	✓
F56	Body	DVDC DVD Changer	✓	✓	✓	✓	○	✓	✓
F56	Body	FZD Function centre,roof	✓	✓	✓	✓	✓	✓	✓
F56	Body	HKL Rear-lid lift	✓	✓	✓	✓	✓	✓	✓
F56	Body	IHKA Heater/automatic A/C control	✓	✓	✓	✓	✓	✓	✓
F56	Body	INSTR Instrument cluster	✓	✓	✓	✓	✓	✓	✓
F56	Body	KAFAS Camera-based driver-assistance systems	✓	✓	✓	✓	✓	✓	○
F56	Body	PMA Parking assistant	✓	✓	✓	✓	✓	✓	○
F56	Body	SMFA Seat module,driver	✓	✓	✓	✓	✓	✓	✓
F56	Body	SZL Switch centre, steering column	✓	✓	✓	✓	✓	✓	✓
F56	Body	ZGM Central Gateway Module	✓	✓	✓	✓	○	○	✓
F56	Body	TRSVc_allround-view camera	✓	✓	✓	✓	✓	✓	○
F56	Chassis	ABS/ASC/DSC Dynamic Stability Control	✓	✓	✓	✓	✓	✓	✓
F56	Chassis	AL active steering	✓	✓	✓	✓	✓	○	✓
F56	Drive	CAS Car Access System	✓	✓	✓	✓	✓	✓	✓
F56	Drive	DME/DDE(Engine Electronics)	✓	✓	✓	✓	✓	✓	✓

F56	Drive	EGS/AGS(Transmission Control)	✓	✓	✓	✓	✓	✓	✓
F55	Body	MRS/AB Airbag/ACSM	✓	✓	✓	✓	✓	○	✓
F55	Body	AHM Trailer module	✓	✓	✓	✓	✓	✓	✓
F55	Body	AMPH Hi-Fi amplifier	✓	✓	✓	✓	✓	✓	✓
F55	Body	AMPT Top Hi-Fi amplifier	✓	✓	✓	✓	✓	✓	✓
F55	Body	ASD Active Sound Design	✓	✓	✓	✓	✓	✓	○
F55	Body	CBX-ECALL Combox emergency call	✓	✓	✓	✓	✓	✓	○
F55	Body	CIC Car Information Computer	✓	✓	✓	✓	✓	✓	✓
F55	Body	CON Controller	✓	✓	✓	✓	✓	✓	✓
F55	Body	DVDC DVD Changer	✓	✓	✓	✓	○	✓	✓
F55	Body	FZD Function centre,roof	✓	✓	✓	✓	✓	✓	✓
F55	Body	HKL Rear-lid lift	✓	✓	✓	✓	✓	✓	✓
F55	Body	IHKA Heater/automatic A/C control	✓	✓	✓	✓	✓	✓	✓
F55	Body	INSTR Instrument cluster	✓	✓	✓	✓	✓	✓	✓
F55	Body	KAFAS Camera-based driver- assistance systems	✓	✓	✓	✓	✓	✓	○
F55	Body	PMA Parking assistant	✓	✓	✓	✓	✓	✓	○
F55	Body	SMFA Seat module,driver	✓	✓	✓	✓	✓	✓	✓
F55	Body	SZL Switch centre, steering column	✓	✓	✓	✓	✓	✓	✓
F55	Body	ZGM Central Gateway Module	✓	✓	✓	✓	○	○	✓
F55	Body	TRSVc_allround-view camera	✓	✓	✓	✓	✓	✓	○
F55	Chassis	ABS/ASC/DSC Dynamic Stability Control	✓	✓	✓	✓	✓	✓	✓
F55	Chassis	AL active steering	✓	✓	✓	✓	✓	○	✓
F55	Drive	CAS Car Access System	✓	✓	✓	✓	✓	✓	✓
F55	Drive	DME/DDE(Engine Electronics)	✓	✓	✓	✓	✓	✓	✓
F55	Drive	EGS/AGS(Transmission Control)	✓	✓	✓	✓	✓	✓	✓
R61	Body	MRS/AB Airbag/ACSM	✓	✓	✓	✓	✓	○	✓
R61	Body	AHM Trailer module	✓	✓	✓	✓	✓	✓	✓
R61	Body	AMPH Hi-Fi amplifier	✓	✓	✓	✓	✓	✓	✓
R61	Body	CA Comfort access system	✓	✓	✓	✓	✓	○	✓
R61	Body	CBX-ECALL Combox emergency call	✓	✓	✓	✓	✓	✓	○
R61	Body	CHAMP-BO User interface	✓	✓	✓	✓	✓	✓	✓
R61	Body	CHAMP-GW Gateway	✓	✓	✓	✓	✓	✓	✓
R61	Body	CID Central information display	✓	✓	✓	✓	✓	✓	✓
R61	Body	FRM footwell module	✓	✓	✓	✓	✓	✓	✓
R61	Body	IBOC Digital tuner US	✓	✓	✓	✓	✓	○	✓
R61	Body	IHKA Heater/automatic A/C control	✓	✓	✓	✓	✓	✓	✓
R61	Body	INSTR Instrument cluster	✓	✓	✓	✓	✓	✓	✓
R61	Body	JBE Junction-box electronics	✓	✓	✓	✓	✓	✓	✓
R61	Body	MJOY MINI joystick	✓	✓	✓	✓	✓	✓	✓
R61	Body	PDC Park distance control	✓	✓	✓	✓	✓	✓	✓
R61	Body	SHD Sliding/tilting sunroof	✓	✓	✓	✓	✓	✓	✓
R61	Body	SZL Steering column switch centre 2	✓	✓	✓	✓	✓	✓	✓
R61	Body	ULF-SBX Interface box	✓	✓	✓	✓	✓	✓	✓
R61	Body	ULF-SBX-H Interface box High	✓	✓	✓	✓	✓	✓	✓
R61	Chassis	ABS/ASC/DSC Dynamic Stability Control	✓	✓	✓	✓	✓	✓	✓
R61	Chassis	EDC Damper Control	✓	✓	✓	✓	✓	✓	✓
R61	Chassis	EPS Electronic Power Steering	✓	✓	✓	✓	✓	✓	✓
R61	Drive	CAS Car Access System	✓	✓	✓	✓	✓	✓	✓
R61	Drive	DME/DDE(Engine Electronics)	✓	✓	✓	✓	✓	✓	✓
R61	Drive	EGS/AGS(Transmission Control)	✓	✓	✓	✓	✓	✓	✓
F57	Drive	CAS Car access system	✓	✓	✓	✓	✓	✓	○
F57	Drive	Engine-DME Digital Motor Electronics	✓	✓	✓	✓	✘	✘	○
F57	Drive	EGS transmission management	✓	✓	✓	✓	✓	✓	○
F57	Chassis	AL active steering	✓	✓	✓	✓	✓	✓	○
F57	Chassis	ABS-DSC Dynamic Stability Control	✓	✓	✓	✓	✓	✓	○
F57	Body	Airbag-ACSM Crash Safety Module	✓	✓	✓	✓	✓	✓	○
F57	Body	AHM trailer module	✓	✓	✓	✓	✓	✓	○
F57	Body	AMPH Hi-Fi amplifier	✓	✓	✓	✓	✓	✓	○
F57	Body	AMPT Top Hi-Fi amplifier	✓	✓	✓	✓	✓	✓	○
F57	Body	ASD Active Sound Design	✓	✓	✓	✓	✓	✓	○
F57	Body	CBX-ECALL ComBox emergency call	✓	✓	✓	✓	✓	✓	○
F57	Body	CIC Car Information Computer	✓	✓	✓	✓	✓	✓	○
F57	Body	CON Controller	✓	✓	✓	✓	✓	✓	○
F57	Body	DSP Digital Sound Processor	✓	✓	✓	✓	✓	✓	○
F57	Body	DVDC DVD changer	✓	✓	✓	✓	✓	✓	○
F57	Body	FZD Function centre,roof	✓	✓	✓	✓	✓	✓	○
F57	Body	HKL Automatic luggage compartment lid actuation	✓	✓	✓	✓	✓	✓	○
F57	Body	IHKA Integrated automatic heating/air conditioning	✓	✓	✓	✓	✓	✓	○
F57	Body	INSTR Instrument cluster	✓	✓	✓	✓	✓	✓	○
F57	Body	KAFAS Camera-based driver- assistance systems	✓	✓	✓	✓	✓	✓	○
F57	Body	PMA Parking assistant	✓	✓	✓	✓	✓	✓	○
F57	Body	SMFA Seat module, driver	✓	✓	✓	✓	✓	✓	○
F57	Body	Airbag-SZL Switch centre, steering column	✓	✓	✓	✓	✓	✓	○
F57	Body	TRSVc_allround-view camera	✓	✓	✓	✓	✓	✓	○
F57	Body	TBX Touchbox	✓	✓	✓	✓	✓	✓	○
F57	Body	ZGM Central Gateway Control Module	✓	✓	✓	✓	✓	✓	○



## Service Function List

Part	Components	Status
Maintenance	CBS reset Key Word Protocol	✓
Maintenance	CBS Reset UDS	✓
Maintenance	CBS reset, engine oil	✓
Maintenance	CBS vehicle data correction	✓
Maintenance	Charging the battery via diagnostic socket	✓
Maintenance	Delete transport mode	✓
Maintenance	Reset pre-delivery check	✓
Maintenance	Setting the transport mode	✓
Engine	Activation fuel pump control module	✓
Engine	Activation/deactivation terminal 15	✓
Engine	Adaptation of fuel quantity control valve	✓
Engine	Adaptation, hot film air mass meter	✓
Engine	Adjusting the starting torque	✓
Engine	Adjustment of exhaust-gas recirculation	✓
Engine	Adjustment of idle speed	✓
Engine	Adjustment, consumption calculation	✓
Engine	Automatic engine start-stop function: Starter exchange	✓
Engine	Automatic engine start-stop function: Teach in zero-gear sensor	✓
Engine	Bleeding the fuel system	✓
Engine	Charging the high-voltage battery: Read out history of last charging procedures	✓
Engine	Composition of the high-voltage battery unit: Read out serial numbers	✓
Engine	Compression test	✓
Engine	Consumption calculation adjustment	✓
Engine	Delete install mode	✓
Engine	Diesel particulate filter: - Request regeneration	✓
Engine	Diesel particulate filter: Replacement	✓
Engine	Diesel particulate filter: Request regeneration	✓
Engine	EGR adaptation	✓
Engine	EGS: Reset adaptation values	✓
Engine	EGS: Teach in neutral position	✓
Engine	EGS: transmission fluid adjustment	✓
Engine	Electronic immobiliser (EWS): Reset starter lock	✓
Engine	EME: Delete install mode	✓
Engine	EME: Read out the adjustment value of the rotor position sensor	✓
Engine	EME: Reset vacuum pump operating time	✓
Engine	EME: Rotor position sensor adjustment	✓
Engine	EME: Teach in parking lock module	✓
Engine	Engine control: Read measured value	✓
Engine	Engine operating values record	✓
Engine	European on-board diagnosis readiness codes	✓
Engine	EWS adjustment	✓
Engine	EWS starting value	✓
Engine	Exhaust-gas recirculation	✓
Engine	Fuel consumption display adjustment	✓
Engine	Fuel quality identification	✓
Engine	Fuel tank pressure sensor adjustment	✓
Engine	Gear sensor	✓
Engine	Idle speed adjustment	✓

Engine	Internal engine pressure	✓
Engine	Learn Valvetronic limit positions	✓
Engine	Mass meter	✓
Engine	Mean quantity adaptation	✓
Engine	MSA: Read history memory	✓
Engine	MSA: System check	✓
Engine	On-board Diagnosis Readiness Codes	✓
Engine	RDME: Delete install mode	✓
Engine	Reading out the readiness codes	✓
Engine	Regulation of switching speed	✓
Engine	Release correction, additive level 1	✓
Engine	Release correction, additive level 2	✓
Engine	REME: Delete install mode	✓
Engine	Reset adaptation values	✓
Engine	Reset production mode	✓
Engine	Reset production mode, preheating control unit	✓
Engine	Reset starter lock	✓
Engine	Reset the internal ELV fault counter	✓
Engine	Service start range extender	✓
Engine	Smooth running control	✓
Engine	Starting torque adjustment	✓
Engine	Starting up the high-voltage battery unit	✓
Engine	Start-up, fuel pump control	✓
Engine	Teach in drive position actuator	✓
Engine	Transmission control unit: Reset adaptation values	✓
Engine	Valvetronic adaptation limit positions	✓
Engine	VANOS adaptation	✓
Engine	Compression test	✓
Chassis	Workshop mode, Automatic Hold brake	✓
Chassis	Adjustment of steering torque sensor	✓
Chassis	Adjustment of the driving dynamics sensors	✓
Chassis	Brake bleeding procedure	✓
Chassis	DSC control unit adjustment	✓
Chassis	DSC: Bleeding routine	✓
Chassis	DSC: Brake line mix-up test	✓
Chassis	DSC: Brake line reversal check	✓
Chassis	DSC: Pressure sensor adjustment	✓
Chassis	DSC: Sensor adjustment	✓
Chassis	DSC: Steering angle sensor adjustment	✓
Chassis	PSC adjustment	✓
Chassis	PSC: Steering start-up	✓
Chassis	Service function, pressure encoding	✓
Chassis	Start-up for brake pedal travel sensor	✓
Chassis	Start-up, Automatic Hold brake	✓
Body	A/C compressor running-in protection	✓
Body	Activate deactivate test card	✓
Body	Activate SDARS	✓
Body	Add tuner section	✓
Body	Analysis of the wake-up control units	✓
Body	Auxiliary heater: Initialisation of the Telearstart transmitter	✓
Body	Calibrating the expansion valves of the heat pump circuit	✓
Body	Calibration run for flap motors	✓
Body	Change personalisation data of remote key	✓
Body	Create boot file again	✓
Body	Delete the personal profile	✓

